


For Everyday Aussie pools



Captura Plus™

Robotic Pool Cleaner


TYPE: EM14 --EM15 --





Before You Start

This Quick Start Guide contains essential installation and startup instructions. For additional operation, maintenance, and troubleshooting instructions, please refer to the complete Owner's Manual. Read the complete manual and all safety warnings before commencing installation. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



	Baracuda Adventura™ Robotic Pool Cleaner
а	handle frame
b	handnut
С	wheels (x 2)
d	wheel axle / hubcap (x 2)
е	base unit
f	caddy handle

1. Important Safety Instructions

READ AND FOLLOW ALL INSTRUCTIONS

Congratulations on purchasing the Baracuda Robotic Cleaner. Please read through the entire manual before installing your new robotic pool cleaner. Your cleaner must be installed and operated as specified.

A WARNING

Failure to comply with the following warnings can increase risk of fire or electrocution which can result in property damage and serious injury, including loss of life.

PREVENT ELECTRICAL SHOCK

To reduce risk of electrical shock:

- The cleaner is to be installed in accordance with the relevant requirements of the Australian wiring rules AS/NZS 3000. Also
 refer to the installation instructions relating to the swimming pool equipment for which the cleaner will be an integral part. The
 cleaner is to be supplied through a Residual Current Device (RCD) with a rated residual operating current of 30mA.
- Do not enter pool while the robotic cleaner is in water.
- Do not bury cord. Locate cord so as to prevent it from being damaged by lawn mowers, hedge trimmers and other equipment.
- To reduce the risk of electrical shock, do not use the robotic cleaner or control unit if the cord is worn or damaged. Contact Baracuda Customer Care Service 1300 784 423 immediately for proper servicing and replacement of the damaged cord.
- Double insulation—For continued protection against possible electric shock, use only identical replacement parts when servicing. Do not attempt repair of the robotic cleaner, control unit, power cord, or floating cable.
- Use only the power supply provided with the product.
- NEVER OPEN CONTROL UNIT.
- DO NOT USE AN EXTENSION CORD TO CONNECT THE UNIT TO ELECTRIC SUPPLY; PROVIDE A PROPERLY LOCATED
 APPROVED ELECTRICAL OUTLET. THE CONTROL UNIT SHOULD BE PLACED NEAR THE APPROVED RECEPTACLE BOX.

PREVENT CHILD INJURY AND DROWNING

- To reduce the risk of injury, do not permit children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge to operate this product.
- Do not let anyone, especially small children, sit, step, lean, or climb on any equipment installed as part of your pool's
 operational system.

A CAUTION

Failure to comply with the following warnings could cause damage to pool equipment or personal injury.


- The robotic cleaner must be installed and operated as specified.
- This product is intended for use with permanently-installed pools. Do not use with storable pools. A permanently-installed pool
 is constructed in or on the ground or in a building such that it cannot be readily disassembled for storage. A storable pool is
 constructed so that it is capable of being readily disassembled for storage and reassembled to its original integrity.
- Clean the filter canister in the Adventura cleaner after each use.
- Do not use the product in your pool if the water temperature is above 35° C (95° F) or below 13° C (55° F).

USE OF THE BARACUDA ROBOTIC CLEANER IN A VINYL LINER POOL

Certain vinyl liner patterns are particularly susceptible to rapid surface wear of pattern removal caused by objects coming into contact with the vinyl surface, including pool brushes, pool toys, floats, fountains, chlorine dispensers, and automatic pool cleaners. Some vinyl liner patterns can be seriously scratched or abraded simply by rubbing the surface with a pool brush. Ink from the pattern can also rub off during the installation process or when it comes into contact with objects in the pool. Fluidra Group Australia Pty. Ltd. is not responsible for, and the Limited Warranty does not cover, pattern removal, abrasion or markings on vinyl liners.

SAVE THESE INSTRUCTIONS

2. Connect Floating Cable



A WARNING

Never turn on the cleaner unless it is fully submerged in the water. Doing so will void the warranty and may cause severe damage to the cleaner motors.

Do not use an extension cord to connect the control unit.

3. Submerge Robotic Cleaner in Pool




Figure 1. Submerge the Cleaner Vertically




Figure 2. Cleaner Sinking to the Bottom of the Pool

Wait for bubbles to stop completely, then let the cleaner sink to the bottom of the pool.





Figure 3. Ideal entry point in pool.

4. Start Cleaning

Press the Start/Stop button to begin cleaning.





Read the complete manual for how to customize cycle time, set schedules, clean intensity, etc.


5. Control Unit




Button Functions		
••••	LEDs indicating pump strength for SCS	
scs	Surface Control System (SCS) for wall cleaning (rough to smooth surfaces)	
STOP)	Start/Stop cleaning	
(i)	Information LED Cleaner Error Indicator	
\Box	Select Cleaning Surface	
	Quick Clean (1h 15 min) Floor only	
	Deep Clean (2h 45 min) Floor, Walls, Waterline, High Intensity	


6. Check Wall Climbing (SCS)

You can change the wall climbing setting at any time during cleaner operation with the SCS button. The new setting will be active when the cleaner climbs the next wall.



- One additional LED lights each time you press the button to indicate stronger grip on the wall.
- To decrease setting, press button to cycle through back to one LED (lowest setting).





7. Proper Removal from Pool

- 1. Press (to interrupt operation.
- 2. When the cleaner is within arm's reach, use the handle to lift it from the water (Figure 4).

NOTE: Never lift the cleaner out of the pool by the floating cable.




Figure 4. Lift Cleaner From Pool with Handle

3. Hold the cleaner vertically over the pool surface to drain water before removing (Figure 5).




Figure 5. Lift Cleaner From Pool with Handle

8. Unplug & Untangle




Figure 6. Unplug the Floating Cable






Figure 7. Untangle the Floating Cable


9. Clean the Filter Canisters

 Press the Push 'n' Go button to release the canister handle.







2. Grasp the handle and lift up to remove the filter canister.




3. Press the two latches on both sides to release the lid.



4. Lift to remove the filter canister lid.



5. Using a hose with clean water, rinse the filter canister and lid to remove all debris.



WARRANTY REGISTRATION



For full warranty terms and conditions and to register your warranty, visit www.baracuda.com.au/warranty and complete your details.

Or scan the QR code to go directly to the registration page.

Record your equipment details here for guick reference:

Model No.:

Serial No. :_____

WARRANTY REGISTRATION



For full warranty terms and conditions and to register your warranty, visit www.baracuda.co.nz/warranty and complete your details.

Or scan the QR code to go directly to the registration page.

Record your equipment details here for quick reference:

Model No. :_____

Serial No. :_____

A Fluidra Brand | Baracuda.com.au | Baracuda.co.nz

Fluidra Group Australia Pty Ltd | 1 Herbert Place, Smithfield NSW 2164, PO Box 7238 Wetherill Park NSW 1851, Australia ABN: 87 002 641 965 | 1300 186 875

Fluidra NZ Ltd \mid 13 Douglas Alexander Parade \mid Rosedale Auckland 0632, New Zealand NZBN: 942 903 181 70759 \mid 0800 807 665